

Instructions for “Sure Hit” Sights

The "Sure Hit" revolver sights come with everything needed to install them on your revolvers and step by step instructions in the package.

1. Start by roughing up the surface of your current sights.



2. Add the metal adhesive per instructions on enclosed card.



3. Place New "Sure Hit" sight over factory sight and let cure per instructions.



4. Adjust the P.O.A once sights have cured.

